

TigerStop[®] fast and accurate...every time

²⁰¹⁷ Application Guide



TigerStop LLC — Assembly Plant, 12909 NE 95th St., Vancouver WA 98682 — Tel: (360) 254-0661 Fax: (360) 260-0755





The Basic TigerStop

TigerStop has 4 major parts:

1. Controller

TigerStop's "brain", comes with a stand for mounting.

2. Motor Box


TigerStop's "brawn", houses motor and amplifier. Receives power, controller and interconnect cables.

3. Fence Beam

TigerStop's "body", houses carriage and drive belt.


4. Flip-Away Stop

TigerStop's "boot", stops or pushes your materials.



R


TigerStop Dimensional Specifications



TigerStop LLC — Assembly Plant, 12909 NE 95th St., Vancouver WA 98682 — Tel: (360) 254-0661 Fax: (360) 260-0755



TigerStop [®] System Length




How to calculate the overall length of a TigerStop system

- 1 Find the TigerStop of the desired length (length shown in the part # is working length) and start your calculation with the overall length shown above. The table under the TigerStop is the same length.
- 2 Measure the overall width of the tool used between the two tables. Add this to the TS overall length.*
- ³ Find the table of the desired length for the opposite side of the tool. Add this length to the calculation. The sum total will be the end to end overall length of the TigerStop system.



TigerStop [®] Beam Saw Stop Setup

TigerStop can be used with virtually any <u>manual</u> beam saw as a stop mounted on the back or the front side. No feed tables are needed for this simple setup. Some models may require on site modifications.



TigerStop front fence mounting.

Order List Details

- (1) TigerStop 06, 08 or 10, with internal line filter, control stand, and standard interconnect. — Used as a *stop*. If used on the back side, the existing back fence of the beam saw must be replaced with TigerStop, mounted to the table edge using UBR brackets. If used on the front side, TigerStop is mounted to the table edge using UBR brackets. In both configurations, the TigerStop motor should be next to the beam in which the saw travels.
- (2) TigerStop UBR brackets are used to mount TigerStop to the either side of the saw.
- (3) The 20' control cable runs under the beam saw and is plugged into the controller mounted near the operator controls.
- (4) The gangstop extends the reach of the stop by 9" to 24" and gives a wider surface to butt your parts against. *TigerStop is always used as a stop in this application, NEVER a pusher!*


ORDER LIST

Refer to numbers in the drawing.

	Description	Part # <u>Size</u>
1	TigerStop	TS
2	UBR Brackets (Qty: 4)	UBR
3	20' Control Cable	CC5-20
4	Gangstop	GSX



TigerStop [®] Horizontal Boring or Mortising Setup



- (5) The back fence keeps material from falling off the opposite feed table. Aluminum 72" segments.
- (6) An 144" long adhesive back rule, mounted to the back fence, is helpful in set point stop optimizing. Order as BRLR (left-to-right reading) or BRRL (right-to-left reading).
- (7) The pusher foot extends the reach of the stop by 10" to 14". Other optional stop attachments are also available, such as the extended pusher foot PFX, the gangstop GSX, the miter gauge MG and extended miter gauge MGX.

* Roll-top feed tables are also available with metal or

plastic rollers on 12" centers for processing heavy

materials. Part # is TABR for steel rollers and

TABR -PR for plastic rollers.



З

 $\mathbf{6}$

TigerStop [®] Chop Saw Setup

8

Some models may require on site modifications.

Chop Saw NOT included!

1

(2

For big savings on a TigerStop Chop Saw Work Station package, refer to the TigerStop Price List!

Optimize your cut lists with this setup!

5

(4)

ORDER LIST

Refer to numbers in the drawing.

	Description	Part # <u>Size</u>
1	TigerStop	TS
2	Infeed/Outfeed Table *	TABNR
3	Saw Support with 2 leg sets	CSS
4	Infeed/Outfeed Table *	TABNR
5	Back Fence (72" long)	BF
6	Back Rule (144" long)	BR -LR/-RL
7	Pusher Foot	PF
8	Label Printer, downloading & optimizing software - DNLD, OPT, PR 2/4, ESC, SX, USBA	

* Roll-top feed tables are also available with metal or plastic rollers on 12" centers for processing heavy materials. Part # is **TABR___** for steel rollers and **TABR____** PR for plastic rollers.


Order List Details

- (1) TigerStop 06 through 30, with internal line filter, control stand, and standard interconnect.
- (2) (4) Infeed/outfeed tables 06 through 30 (non-roller).
- (3) Saw supports come with two leg sets to support adjacent tables.
- (5) The back fence keeps material from falling off the opposite feed table. Aluminum 72" segments.
- (6) An 144" long adhesive back rule, mounted to the back fence, is helpful in set point stop optimizing. Order as BRLR (left-to-right reading) or BRRL (right-to-left reading).
- (7) The pusher foot extends the reach of the stop by 10" to 14". Other optional stop attachments are also available, such as the extended pusher foot PFX, the gangstop GSX, the miter gauge MG and extended miter gauge MGX.



TigerStop ® Double Miter Saw Setup

Some models may require on site modifications.



Order List Details

- (1) TigerStop 06, 08 or 10, with internal line filter, control stand, and standard interconnect.
- (2) (4) Infeed/outfeed tables 06 through 24 (non-roller) The feed table under the TigerStop should be the same length as the machine. The feed table on the opposite side of the work station should be long enough to handle your *longest stock length* (used as a *stop*) or your *longest finished pieces* (used as a *pusher*).
- (3) Extra leg sets are needed to support infeed/outfeed tables when it is not possible to attach them to a free-standing tool.
- (5) The back fence in this application is used as a front fence on the infeed table to line up the stock with the front fences on the miter saw and on the TigerStop outfeed table. Aluminum
- 72" segments.
- (6) The pusher miter is a stop attachment used in this application. Other stop attachments can be added to extend the reach, such as a pusher foot **PF** or miter gauge **MG**.


The pusher miter fence (rail) is an aluminum front fence with a sliding follower (guide) that attaches to the pusher miter to keep it in perfect alignment.

	Description	Part # <u>Size</u>
1	TigerStop	TS
2	Infeed/Outfeed Table *	TABNR
3	Extra Leg Sets (Qty: 2)	TABLEG
4	Infeed/Outfeed Table *	TABNR
5	Back Fence (72" long)	BF
6	Pusher Miter & Fence	PM

4

* Roll-top feed tables are also available with metal or plastic rollers on 12" centers for processing heavy materials. Part # is **TABR**_____for steel rollers and **TABR**____-**PR** for plastic rollers.





Metalworking applications only:

- All feed tables should be assumed free standing with metalworking machines for clearance issues.
- All machines should be with home end motors (or amplifiers), AWAY from tool.

Order List Details

- (1) TigerStop 06 through 30, with internal line filter, control stand, and standard interconnect.
- (2) (4) Infeed/outfeed tables 06 through 30 (roller).
- (3) Extra leg sets are needed to support tables.
- (5) The back fence keeps material from falling off the opposite feed table. Aluminum 72" segments.
- (6) The pusher foot extends the reach of the stop by 10" to 14". Other attachments available are the extended pusher foot PFX, the gangstop GSX, the miter gauge MG and extended miter gauge MGX.
- (7) A controller cover is recommended in a metal-working environment.
- (8) Optional 20' or 30' long controller cable will be necessary if using TigerStop as a Home End machine, with motor AWAY from the tool.
- (9) Extended IO Cable to connect 9 IOC6-X, SIK / AIK (Size of TS will determine length of extension)


ORDER LIST

Refer to numbers in the drawing.

	Description	Part # <u>Size</u>
1	TigerStop	TS
2	Infeed/Outfeed Table *	TABR
3	Extra Leg Sets (Qty: 2)	TABLEG
4	Infeed/Outfeed Table *	TABR
5	Back Fence (72" long)	BF
6	Pusher Foot	PF
	Optional: For metal applications only	
7	Controller Cover	CON5CVR
8	20' / 30' Control Cable, Co	C5-20 -30

* Roll-top feed tables are also available with plastic rollers for processing anodized aluminum stock. Part # is TABR _____ -PR for plastic rollers. Non-roller feed tables are also available: **TABNR**





Order List Details

- (1) TigerStop 06 through 30, with internal line filter, control stand, and standard interconnect.
- (2) (4) Infeed/outfeed tables 06 through 30 (roller) See option at item (3).
- (3) Extra leg sets are needed to support infeed/outfeed tables. Substitute a saw support (which includes 2 leg sets) for these two leg sets if using a bench mortiser.
- (5) The back fence keeps material from falling off the opposite feed table. Aluminum 72" segments.
- (6) The pusher foot extends the reach of the stop by 10" to 14". Other optional stop attachments are also available, such as the extended pusher foot PFX, the gangstop GSX, the miter gauge MG and extended miter gauge MGX.

* Non-roller feed tables are also available, part #: **TABNR10.** Other lengths available.


ORDER LIST

Refer to numbers in the drawing.

	Description	Part # Size
1	TigerStop	TS
2	Infeed/Outfeed Table *	TABR
3	Extra Leg Sets (Qty: 2)	TABLEG
4	Infeed/Outfeed Table *	TABR
5	Back Fence (72" long)	BF
6	Pusher Foot	PF
3	Saw Support	
	with 2 leg sets	CSS







Some models may require on site modifications.



Refer to numbers in the drawing.

Description

1 TigerCrossCut

Part # Size TCC

Order List Details

(1) TigerCrossCut, with internal line filter and control stand. Totally replaces the cross cut gauge on your sliding bed panel saw.






Some models may require on site modifications. Mounting bar for the controller is NOT included. Sliding panel saw **NOT included!** T Ð





TigerStop [®] Vertical Panel Saw Setup

Some models may require on site modifications.



ORDER LIST

Refer to numbers in the drawing.

- DescriptionPart # Size1TigerStopTS
- 2 Universal Brackets UBR


Order List Details

- (1) TigerStop 06, 08 or 10, with internal line filter, control stand, and standard interconnect.
- (2) TigerStop brackets are used to mount TigerStop to the horizontal support member of the panel saw. Use 1 bracket for every 3' of TigerStop OA length.



TigerStop [®] Radial Arm Saw Setup

Some models may require on site modifications.



Order List Details


- (1) TigerStop 06 through 30, with internal line filter, control stand, and standard interconnect.
- (2) (4) Infeed/outfeed tables 06 through 30 (non-roller).
- (3) (5) Two extra leg sets to support tables.
- (6) The back fence keeps material from falling off the opposite feed table. Aluminum 72" segments.
- (7) An 144" long adhesive back rule, mounted to the back fence, is helpful in set point stop optimizing. Order as BRLR (left-to-right reading) or BRRL (right-to-left reading).
- (8) The gangstop extends the reach of the stop by 9" to 24". Other optional stop attachments are also available, such as the pusher foot PF and extended pusher foot PFX, the miter gauge MG and extended miter gauge MGX.

	Description	Part # <u>Size</u>
1	TigerStop	TS
2	Infeed/Outfeed Table *	TABNR
3	Extra Leg Set	TABLEG
4	Infeed/Outfeed Table *	TABNR
5	Extra Leg Set	TABLEG
6	Back Fence (72" long)	BF
7	Back Rule (144" long)	BR -LR/-RL
8	Gangstop	GSX
9	Label Printer, downloadin	g & optimizing
	software - DNLD, OPT, PR 2/4, ES	SC, SX, USBA

* Roll-top feed tables are also available with metal or plastic rollers on 12" centers for processing heavy materials. Part # is **TABR**_____ for steel rollers and **TABR**____**-PR** for plastic rollers.







Pneumatic control of anti-kickback lever

The user can control the lever raising and lowering the anti-kickback device by mounting a pneumatic cylinder and shackle to the lever. The air supply must run through a solenoid valve IKSV2 (item 2) plugged into the TigerFence I/O port, using an IOC6 (item 3).

ORDER LIST

Refer to numbers in the drawing.

	Description	Part #
1	TigerFence	TF-SLR
	Optional, if using a pneuma	tic control.
2	Solenoid Valve	IKSV2
3	I/O Cable	IOC6

Order List Details

(1) TigerFence, custom-length. — Order a custom length as described below.


How to order a custom length TigerFence

Use the overall *width* of your rip saw table as the overall *length* of the TigerFence. The TigerFence *working length* equals the *throat depth* of your rip saw (usually 12") and will be set by positioning the TigerFence limit switches appropriately.





All models may require some on site modifications.



Order List Details

- (1) TigerFence. Order a standard length TigerFence.
- (2) The side table adds extra width to the existing saw table and provides additional anchoring for TigerFence.

ORDER LIST

Refer to numbers in the drawing.	
Description Part #	
TigerFence	TF
Table Saw Side Table	TABP

TigerStop LLC — Assembly Plant, 12909 NE 95th St., Vancouver WA 98682 — Tel: (360) 254-0661 Fax: (360) 260-0755

1

2



TigerStop[®] Up-Cut Saw Setup

Some models may require on site modifications.

Up-Cut Saw NOT included!

For big savings on a TigerStop Up-Cut Saw Work Station package, refer to the TigerStop Price List! 8 (6)(5) 3 Part # CLIP **Optimize your cut lists** with this setup!

Order List Details

- (1) TigerStop 06 through 30, with internal line filter, control stand, and standard interconnect.
- (2) (4) Infeed/outfeed tables 06 through 30 (non-roller).
- (3) Saw attachment plates attach feed tables to free-standing tools.
- (5) The back fence keeps material from falling off the opposite feed table. Aluminum 72" segments.
- (6) An 144" long adhesive back rule, mounted to the back fence, is helpful in set point stop optimizing. Order as BRLR (left-to-right reading) or BRRL (right-to-left reading).
- (7) The pusher foot extends the reach of the stop by 10" to 14". Other optional stop attachments are also available, such as the extended pusher foot PFX, the gangstop GSX, the miter gauge MG and extended miter gauge MGX.

Add Clipboard to this setup!

4


Clipboard, a TigerStop software application that replaces printed cut lists and the clipboard that often holds them, lets the operator control TigerStop and organize work orders from a touch screen (NOT included).

ORDER LIST

Refer to numbers in the drawing.

		-	
	Description	Part # <u>Size</u>	
1	TigerStop	TS	
2	Infeed/Outfeed Table *	TABNR	
3	Saw Attachment Plates	SAP (Qty: 2)	
4	Infeed/Outfeed Table *	TABNR	
5	Back Fence (72" long)	BF	
6	Back Rule (144" long)	BR -LR/-RL	
7	Pusher Foot	PF	
8	Label Printer, downloadin software	ig & optimizing	
	- DNLD, OPT, PR 2/4, ES	SC, SX, USBA	
* D	* Poll top food tables are also available with motal or		

* Roll-top feed tables are also available with metal or plastic rollers on 12" centers for processing heavy materials. Part # is TABR____ for steel rollers and **TABR** -PR for plastic rollers.



(8) The pusher foot extends the reach of the stop by 10" to 14". Other optional stop attachments are also available, such as the extended pusher foot **PFX**, the gangstop **GSX**, the miter gauge **MG** and extended miter gauge **MGX**.



TigerStop [®] Double Ended Setup

TigerStop can be used between two pieces of equipment when ordered with the Double Ended option that lets the user calibrate the stop from either end of the fence beam. Some saws / tools may require on site modifications.

6 Saws NOT included! (4) TigerStop controller is moved to the other end and mounted in an extra (6)controller base when using the opposite tool. 2 5 Detail of MG Miter Gauge. 4 Not available **ORDER LIST** w/v5 electronics Refer to numbers in the drawing. Part # Size Description 1 TigerStop TS___ 2 Outfeed Table * TABNR Order List Details CSS 3 Saw Support (1) TigerStop 06 through 30, with internal line filter, control stand, with 2 leg sets and standard interconnect. 4 Infeed Tables * (Qty:2) TABNR (2) (4) Infeed/outfeed tables 06 through 30 (non-roller). 5 Back Fence (72" long) BF (3) Saw supports come with two leg sets to support adjacent tables.

- (5) The back fences keep material from falling off the infeed tables.
- Aluminum 72" segments.
- (6) The pusher foot extends the reach of the stop by 10" to 14". Other optional stop attachments are also available, such as the extended pusher foot **PFX** and the gangstop **GSX**.
- (7) The miter gauge (see detail, above) extends the reach of the stop by 2" to 19". Other optional stop attachments are also available, such as the extended miter gauge **MGX**.

* Roll-top feed tables are also available with metal or plastic rollers on 12" centers for processing heavy materials. Part # is **TABR____** for steel rollers and **TABR____** -**PR** for plastic rollers.

6 Pusher Foot

Miter Gauge

Double Ended

7

8

PF

MG

TDE





5

TigerStop and TigerFence can team up with a radial arm saw, a table saw and a return conveyor between them to create a lean one-operator work station!

Some saws / tools may require on site modifications.

 $\mathbf{6}$

Saws and conveyor

are NOT included!

Pictured: TigerStop in STOP mode with radial arm saw.

Order List Details

- (1) TigerStop 06 through 30, with internal line filter, control stand, and standard interconnect.
- (2) (4) Infeed/outfeed tables 06 through 30 (non-roller).
- (3) Extra leg sets to support tables.
- (5) The back fence keeps material from falling off the opposite feed table. Aluminum 72" segments.
- (6) The gangstop extends the reach of the stop by 9" to 24". Other optional stop attachments are also available, such as the pusher foot PF and extended pusher foot PFX, the miter gauge MG and extended miter gauge MGX.
- (7) TigerFence Order a standard length TigerFence.
- (8) The side table adds extra width to the existing saw table and provides additional anchoring for TigerFence. *Depending on the make and model of table saw, this item may not be necessary.*

ORDER LIST

Refer to numbers in the drawing.


4

	Description	Part # <u>Size</u>
1	TigerStop	TS
2	Infeed/Outfeed Table *	TABNR
3	Extra Leg Sets (Qty: 2)	TABLEG
4	Infeed/Outfeed Table *	TABNR
5	Back Fence (72" long)	BF
6	Gangstop	GSX
7	TigerFence	TF
8	Table Saw Side Table	TABP

* Roll-top feed tables are also available with metal or plastic rollers on 12" centers for processing heavy materials. Part # is **TABR**_____ for steel rollers and **TABR**____**-PR** for plastic rollers.



TigerStop[®] HD2 Horizontal Band Saw Bundle Cutting Stop Setup



Horizontal band saws...

- ...are used either to cut **bundles** with TigerStop as a **stop**, *or*...
- ...to cut **single piece** stock as a **push feeder** or, less commonly, as a **stop** system, *and*... ...usually feeds at 14"~16" off the floor.

Some models may require on site modifications.

Horizontal Band Saw NOT included!

6 Not pictured.

ORDER LIST

Refer to numbers in the drawing.

- DescriptionPart # Size1TigerStop HD2HD2R-0212Infeed/Outfeed TableTABR223Extra Leg Sets (Qty: 2)TABLEG
- S EXII a Leg Sets (Qty. 2) TABL
- 4 Infeed/Outfeed Table TABR22
- 5 Back Fence (72" long) BF (Qty: 4)
- 6 20' / 30' Control Cable CC5-20, -30
- 7 Controller Cover

All feed tables should be assumed free standing with metalworking machines for clearance issues. All machines should be with home end motors (or amplifiers), AWAY from tool.

CON5CVR

Order List Details

- (1) Heavy Duty² 21, overall length 24', with internal line filter, control stand, standard interconnect (SIK) and pusher arm. — Select the gear box ratio that matches the material weight you need to push. (See max loads in Order List).
- (2) (4) Infeed/outfeed tables (roller top) The leg stands may require on site height adjustment. Cut them down to feed height.
- (3) Extra leg sets are needed to support infeed/outfeed tables.
- (5) The back fence keeps material from falling off the opposite feed table. Aluminum 72" segments. Four pieces are needed.
- (6) A 20' or 30' long controller cable is necessary.
- (7) A controller cover is recommended in a metal-working environment.

Horizontal band saws should not be set up with an AIK (Advanced Interconnect & Safety Kit) because the cycle time of the tool is too slow. Consult TigerStop for additional details.

21 fast and accurate...every time

(6)

3

TS20

TigerStop[®] Horizontal Band Saw Single Cutting Stop or Push Feed Setup

Horizontal band saws...

- ...are used either to cut **bundles** with TigerStop as a **stop**, *or*...
- ...to cut **single piece** stock as a **push feeder** or, less commonly, as a **stop** system, *and*... ...usually feeds at 14"~16" off the floor.

Some models may require on site modifications.

10)Not pictured.

ORDER LIST

Refer to numbers in the drawing.

- Description Part # Size
- 1 TigerStop
- 2 Infeed/Outfeed Table TABR20
- 3 Extra Leg Sets (Qty: 2) TABLEG
- 4 Infeed/Outfeed Table TABR20
- 5 Back Fence (72" long) BF (Qty: 4)
- 6 20' / 30' Control Cable CCS-20, -30
- 7 Controller Cover CONSCVR
- 8 Gangstop GSX
 - Optional: For ferrous materials only
- 9 Face Plates FP06 (Qty: 3), FP04 (Qty:1) Optional: For anodized alum stock
- 10 Plastic Rollers PR (Qty: 44)
- " #All feed tables should be assumed free standing with metalworking machines for clearance issues.
- " #All machines should be with home end motors (or amplifiers), AWAY from tool.

Horizontal Band Saw NOT included!


Order List Details

- (1) TigerStop 20 (overall 22' long), with internal line filter, control stand, and standard interconnect. Other lengths available.
- (2) (4) Infeed/outfeed tables (roller top) The leg stands may require on site height adjustment. Cut them down to feed height.
- (3) Extra leg sets are needed to support infeed/outfeed tables.
- (5) The back fence keeps material from falling off the opposite feed table. Aluminum 72" segments. Four pieces are needed.
- (6) A 20' or 30' long controller cable is necessary.
- (7) A controller cover is recommended in a metal-working environment.
- (8) The gangstop extends the reach of the stop by 9" to 24". Other optional stop attachments are also available, such as the pusher foot PF and extended pusher foot PFX.
- (9) If processing ferrous materials, protective face plates are recommended to clad the working side of the TigerStop aluminum beam.
- (10) If processing anodized aluminum stock, non-marking plastic rollers for the tables are recommended.

" #Horizontal band saws should not be set up with an AIK (Advanced Interconnect & Safety Kit) because the cycle time of the tool is too slow. Consult TigerStop for additional details.




TigerStop ® Metal Brake Stop Setup



(3) The gangstop extends the reach of the stop by 9" to 24" and is used as a squaring jig for the stock.



TigerStop [®] Cold Saw Setup



Order List Details

- (1) TigerStop 06 through 30, with internal line filter, control stand, and standard interconnect.
- (2) (4) Infeed/outfeed tables 06 through 30 (roller).
- (3) Extra leg sets are needed to support infeed/outfeed tables when it is not possible to attach them to a free-standing tool.
- (5) The back fence keeps material from falling off the opposite feed table. Aluminum 72" segments.
- (6) An 144" long adhesive back rule, mounted to the back fence, is helpful in set point stop optimizing. Order as BRLR (left-to-right reading) or BRRL (right-to-left reading).
- (7) The extended pusher foot extends the reach of the stop by 13" to 33". Other optional stop attachments are also available, such as the pusher foot PF, the gangstop GSX, and the center pusher CP (use with self-centering vise only).


	Description	Part # <u>Size</u>
1	TigerStop	TS
2	Infeed/Outfeed Table *	TABR
3	Extra Leg Sets (Qty: 2)	TABLEG
4	Infeed/Outfeed Table *	TABR
5	Back Fence (72" long)	BF
6	Back Rule (144" long)	BR -LR/-RL
7	Extended Pusher Foot	PFX
	or Center Pusher	CP *
	* See note at drawing and ord	ler list details.
8	Label Printer, downloadii software	ng & optimizing
	- DNLD, OPT, PR 2/4, ES	C, SX, USBA

* Roll-top feed tables are also available with plastic rollers for processing anodized aluminum stock. Part # is TABR _____ -PR for plastic rollers. Non-roller feed tables are also available: **TABNR**



TigerStop [®] Ironworker <u>Punch Setup</u>

Some models may require on site modifications.



- □ All feed tables should be assumed free standing with metalworking machines for clearance issues.
- □ All machines should be with home end motors (or amplifiers), AWAY from tool.

Ironworkers have 3 stations:

1. Shear, usually feeds at 26"~28" off the floor,

	Description	Part # <u>Size</u>
1	TigerStop	TS
2	Infeed/Outfeed Table	TABR
3	Extra Leg Sets (Qty: 2)	TABLEG-
4	Infeed/Outfeed Table	TABR
5	Back Fence (72" long)	BF
6	20' / 30' Control Cable	CC5-20, -30
7	Controller Cover	CON5CVR
8	Gangstop	GSX



TigerStop [®]HD2Ironworker <u>ShearSetup</u>

Ironworker NOT included! Some models may require on site modifications.

Ironworkers have 3 stations:

- 1. Shear, usually feeds at 26"~28" off the floor, normally TigerStop or TigerStop HD2 in PUSH mode.
- 2. Punch, usually feeds at 35" off the floor, normally TigerStop in PUSH mode.
- 3. Die Set, same side as Shear, but above it, can use TigerStop, but uncommon.

Ironworkers can be fitted with a TigerStop on Shear or Punch, or on both.

Consult TigerStop for additional details.

Not pictured.

AlK (Advanced Interconnect). For safety, regardless of the type of machine that the Advanced Interconnect is installed on, there must be a way to immediately cut power to the tool in an emergency. To accomplish this, the kill line and safety switch must be installed.

The kill line is run along the entire length of the infeed table and down to the machine tool. The safety switch has electrical contacts that are closed after the kill line is tensioned and the reset button pushed. If the operator applies pressure to the kill line, both contacts open up, immediately cutting power to TigerStop.

ORDER LIST

3

Refer to numbers in the drawing.

	Description	Part # Size
1	TigerStop HD2 Select the gear box ratio:	HD2R-021
2	Infeed Tables (Qty: 4)	TABW4R
3	Extra Wide Leg Set	TABLEG-W
4	Advanced Interconnect AIK Special 20' long power cord needed.	
5	Controller Cover	CON5CVR

OPTIONAL:

6 20' / 30' Control Cable CC5-20, -30

All feed tables should be assumed free standing with metalworking machines for clearance issues.

Order List Details

- (1) Heavy Duty² 21, overall length 24', with internal line filter, control stand, and pusher arm. Select the gear box ratio that matches the weight you need to push. (See max loads in Order List).
- (2) Extra wide infeed tables, 28" wide by 6' long (with rollers).
- (3) An extra wide leg set is needed to support the table nearest the shear.
- (4) Advanced interconnect kit is recommended for this application. Order it with optional 20' power cord.

Be sure to have all necessary guards in place for operator safety.


- (5) A controller cover is recommended in a metal-working environment.
- (6) Optional 20' or 30' long controller cable may be necessary, depending on your placement of the controller. If installed as in the picture, the standard cable (included) will be long enough.

WARNING: TigerStop, TigerFence, TigerCross Cut, TigerRip Fence and TigerStop Heavy Duty 2 (HD2) are machine components intended for use in conjunction with other potentially dangerous machinery. The use of these components does not make that machinery safe. TigerStop LLC's products are not intended to substitute, in any manner, for safety requirements in general, or in conjunction with other machinery. These components must be incorporated into machinery by persons qualified to design safety features to make the machine as safe as possible and to ensure that it meets federal, state and local law with respect to safety and all other regulatory requirements. In addition, TigerStop Heavy Duty 2 (HD2) are machine components that should only be operated by qualified to despend to ensure that is despendent to safety features. Illustrations of TigerStop and TigerStop Heavy Duty 2 (HD2) are machine do to show, safety features necessary to make the machinery safe to operate.



TigerStop ® OBI Press Setup

Some models may require on site modifications.



ORDER LIST

Refer to numbers in the drawing.

TS

ΒF

GSX

- Description Part # <u>Size</u>
- 1 TigerStop
- 2 Infeed/Outfeed Table * TABR____
- 3 Extra Leg Sets (Qty: 2) TABLEG
- 4 Infeed/Outfeed Table * TABR____
- 5 Back Fence (72" long)
- 6 Gangstop

* Roll-top feed tables are also available with plastic rollers for processing anodized aluminum stock. Part # is **TABR____PR** for plastic rollers. Non-roller feed tables are also available: **TABNR____**.

Order List Details

- (1) TigerStop 06 through 30, with internal line filter, control stand, and standard interconnect.
- (2) (4) Infeed/outfeed tables 06 through 30 (roller)
- (3) Extra leg sets are needed to support infeed/outfeed tables.
- (5) The back fence keeps material from falling off the opposite feed table. Aluminum 72" segments.
- (6) The gangstop extends the reach of the stop by 9" to 24" and gives a wider surface to butt your parts against.

Metalworking applications only:

- All feed tables should be assumed free standing with metalworking machines for clearance issues.
- □ All machines should be with home end motors (or amplifiers), AWAY from tool.



ORDER LIST #2 TCC on Infeed Side

Refer to numbers in the drawing.

	Description	Part # Size	
5	TigerCrossCut	TCC	
2	UBR (Qty: 3)	UBR	

which is mounted to the table edge using UBR mounting brackets, with the motor next to the shear.

(2) TigerStop brackets to mount TigerStop off the back edge of the shear table, or TigerCrossCut off the back edge of the infeed.

(3) The 20' control cable runs under the shear and is plugged into the controller mounted near the operator controls.

(4) The gangstop extends the reach of the stop by 9" to 24" and gives a wider surface to butt your parts against.

(5) TigerCrossCut, with internal line filter and control stand. — Used as a stop. Mounted to the front feed table or ledge of a metal shear using UBR mounting brackets.



TigerStop [®] and Your Computer

A basic TigerStop may be a good place to start, but once you've used your machine and realized how much faster and easier it would be if you could integrate TigerStop with your computer, it's time to look at TigerStop's software upgrades.

Upgrade any TigerStop quickly and easily!

Talk to your TigerStop!

SFT Control TigerStop's position from a remote PLC or computer using your own custom pro-TigerSet[®] gramming. Just run a cable from your PC to the RS232 port on the controller.

Run TigerStop from the Bars! BCS + SET

Part # Product

Clipboard[®]

Windows XP,

2000 or NT

required!

TigerGauge®

TG

OPT

Use bar code labels to control TigerStop. If your part list is output on labels in bar code, you Bar Code can use our bar code scanner to send the stop to the right length quickly and easily. When the Scanner part is cut, apply the label.

No more parts cut twice by mistake!

CLIP Super-size your Controller!

Use Clipboard software to turn your touch screen into a TigerStop controller plus! Get a visual real-time view of job progress as Clipboard dynamically updates your part list as you run it. Touch screen NOT included!

Clipboard works with Cabnetware, SuperDoor, GDS, Caliburn, Paradigm, and even your custom program!

Inset moulding cuts on the fly!

TigerGauge software and a digital caliper together provide a superior solution for all TigerStop linear positioning products, a fast and accurate measuring and data entry tool specifically designed for inset moulding. Digital caliper NOT included!

Make the most of your material!

TigerOptimizer[®] is a true "best fit" system that operates on downloaded or manually entered part lists. Specify head and tail cuts either globally or on a per job basis. Configure TigerOptimizer[®] to process stock in a waste first or waste last mode. Get yield and optimization data to track material flow and saw utilization.

Take total control from part list to product! DNLD

Streamline work order flow, manage, schedule, organize, release, prioritize and monitor the Cut List status of every job! Sort parts, label parts, merge multiple jobs for maximum optimization! On Workflow Manager is a powerful tool for managing part lists and routing them to one or more TigerStops. This simple, intuitive computer program makes it easy to Demand[®] maximize efficiency and increase productivity. Available for Ethernet, serial, or USB. Windows XP Workflow Manager works with Cabnetware, Cabinetvision, KCDw, SuperDoor and other programs required! even MS Excel! The PR214 series is enabled for printing and includes a 2/4" label printer.

fast and accurate...every time

gerStop

29

TigerStop Contact Information

Contact Person	Office Phone	E-Mail
	United States and Canada	
Vice President Sale	s & Service	
Jack Ragan	360-448-6140	jragan@tigerstop.com
South West Region	nal Sales	
Mike Arnott	913-660-2350	marnott@tigerstop.com
MidWest Regional S	ales	
Scott Brode	360-314-8958	sbrode@tigerstop.com
NorthEast Regional	Sales	
Erland Russell	513-515-7489	erussell@tigerstop.com
SouthEast Regional	Sales	
Kevin Trowell	407-301-0203	ktrowell@tigerstop.com
NorthWest Regiona	I Sales	
John Gorny	360-600-6453	jgorny@tigerstop.com
Mexico Sales		
Gregorio Aspeitia	001+52+1-553-966-3136	gaspeitia@tigerstop.com
Australia, New Zeala	and & International Sales	
Mathias Forsman	360-448-6157	mforsman@tigerstop.com
Saw Systems Product	t Manager	
Mike Anderson	704-526-9423	manderson@tigerstop.con
Marketing		
Simon Spykerman	360-448-6106	sspykerman@tigerstop.con
	Key Support Contacts	
Technical Support *	Parts Orders * Ship Dates * Tracking Numbe	rs * Lead Times
Service	360-448-6102	service@tigerstop.com
Accounting * Invoice	s * Payments	
Sherrie Kuchta	360-448-6137	skuchta@tigerstop.com
Machine and Parts	Orders	
Machine Orders		orders@tigerstop.com
Spare Part Orders		service@tigerstop.com



Industry/ApplicationIndex

Find your industry and your application and discover your solution with TigerStop!

SOLUTION — TigerStop and your				
chop saw, 6; upcut saw, 16				
upcut saw, 16, 17; double ended,18				
chop saw, 6; upcut saw, 16, 17				
chop saw, 6; upcut saw, 16, 17				
chop saw, 6; upcut saw, 16, 17				
horiz-mortiser, 5; vert-mortiser, 9				
chop saw, 6; dbl-miter saw, 7; double ended, 18				
chop saw, 6; upcut saw, 16, 17 radial arm saw, 13; table saw, 15; rip saw, 14; beam saw, 1;				
ret-conveyor saws, 19; vert-pnl saw, 12				
horiz-boring mach, 5; drill press, 8				
upcut saw, 16, 17				
chop saw, 6; upcut saw, 16, 17; dbl-miter saw, 7				
chop saw, 6; upcut saw, 16, 17; radial arm saw, 13;				
table saw, 15; rip saw, 14 chop saw, 6; upcut saw, 16				
horiz-mortiser, 5; vert-mortiser, 9				
chop saw, 6; upcut saw, 16				
horiz-boring mach,5; drill press, 8				
drill press, 8; ironworker, 24				
ironworker, 25; shear, 27 brake, 22				
Sidile, 22				
cold saw, 23; ironworker, 25; horiz-band saw, 21				
cold saw, 23; ironworker, 25; horiz-band saw, 21				
chop saw, 6; upcut saw, 16, 17				
upcut saw, 7 dbl-miter saw, 7; double ended, 18				
chop saw, 6; radial arm saw, 13; upcut saw, 16, 17;				
double ended, 18; table saw, 15; rip saw, 14; beam saw, 1;				
vert-panel saw, 12				
chop saw, 6; upcut saw, 16, 17; rip saw, 11;				
horiz-boring mach, 5; drill press, 8 horiz-boring mach,5; drill press, 8				
drill press, 8; ironworker, 24				
ironworker, 25; shear, 27				
brake, 22				
drill press, 8; cold saw, 23; ironworker, 24, 25				
radial arm saw, 13 cold saw,16; horiz-band saw, 19, 20				
chop saw, 6; upcut saw, 16,17; dbl-miter saw, 7				
windows, vinyl window parts, cutting chop saw, 6; upcut saw, 16,17; dbl-miter saw, 7 windows, wood				
chop saw, 6; upcut saw, 16,17				

Typical order lists with considerations can be found at the pages listed. TigerStop LLC — Assembly Plant, 12909 NE 95th St., Vancouver WA 98682 — Tel: (360) 254-0661 Fax: (360) 260-0755



lication Guide 2017

TigerStop®

Band Saw (Horizontal)

Single Cutting

METAL

21

METAL

WOOD WOOD METAL METAL With Ledge Stand 17 TigerStop[®] Clipboard TigerStop Up-Cut Saw Setup Double Ended Setup 18 16



Band Saw (Horizontal)



TigerStop Cold Saw Setup 23








WOOD

TigerStop® Metal Brake Setup 22



Ironworker Shear Setup 25

TigerStop® and Your Computer 28 TigerStop® Sales Zones & Contacts 29 Industry/Application Index 30

TigerStop LLC — Assembly Plant, 12909 NE 95th St., Vancouver WA 98682 — Tel: (360) 254-0661 Fax: (360) 260-0755