


# Hydro-pneumatic blind rivet setting tools

## TAUREX 5-6



# Hydro-pneumatic blind rivet setting tools

## TAUREX 5-6

| Spare part no. | TAURUS®-Type | Article no. | Designation                       |
|----------------|--------------|-------------|-----------------------------------|
| 1              |              | 145 1025    | Tool head, assembled              |
| 2              |              | 143 5612    | Sealing ring M4                   |
| 3              |              | 144 6013    | Oil screw plug                    |
| 4 •            |              | 143 6044    | O-ring                            |
| 5 •            |              | 143 6045    | O-ring                            |
| 6              |              | 143 6035    | Seal holder, complete             |
| 7 •            |              | 143 6047    | O-ring                            |
| 8 •            |              | 143 6048    | Rod seal                          |
| 9              |              | 143 6036    | Draw bar                          |
| 10 •           |              | 143 6049    | Cylinder seal                     |
| 11 •           |              | 143 6052    | Supporting ring                   |
| 12 •           |              | 143 6051    | Piston seal                       |
| 13             |              | 143 6046    | O-ring                            |
| 14             |              | 145 8012    | Resetting piston, complete        |
| 15 •           |              | 143 6050    | Lip ring                          |
| 16             |              | 143 6053    | Rod seal                          |
| 17             |              | 144 6123    | Spring                            |
| 18             |              | 143 6030    | Connecting piece                  |
| 19             |              | 144 6124    | V-profile ring                    |
| 20             |              | 144 6125    | Washer                            |
| 21             |              | 143 6042    | O-ring                            |
| 22             |              | 145 7645    | O-ring                            |
| 23             |              | 143 6034    | End cap                           |
| 24             |              | 144 6122    | Retaining spring                  |
| 25             |              | 143 6026    | Retainer                          |
| 26             |              | 143 6028    | Adapter                           |
| 27             |              | 143 6025    | Lock washer                       |
| 28             |              | 143 6029    | Connecting piece nut              |
| 29             |              | 143 6058    | Spent mandrel container, complete |
| 30             |              | 143 5590    | O-ring                            |
| 31 •           |              | 143 5472    | Flat gasket                       |
| 32             |              | 145 7748    | Grip complete                     |
| 33             |              | 144 6025    | Activation button                 |
| 34             |              | 143 5642    | Slider                            |
| 35             |              | 143 5686    | Orifice                           |
| 36 •           |              | 143 5480    | Flat gasket 2                     |
| 37             |              | 144 6126    | Head adapter                      |
| 38             |              | 144 6130    | Screw-in connection               |
| 39             |              | 144 6132    | Coding ring, green                |
| 40             |              | 144 6133    | Coding ring, red                  |
| 41             |              | 144 5393    | PA tube Ø 6 green (L = 10 mm)*    |
| 42             |              | 144 5395    | PA tube Ø 6 red (L = 10 mm)*      |
| 43             |              | 144 6134    | PU tube                           |
| 44             |              | 144 6138    | Screw connection                  |

• Wearing parts

\* The length required must always be specified on the order; the article numbers always refers to the price per metre.

| Spare part no. | TAURUS®-Type | Article no. | Designation                         |
|----------------|--------------|-------------|-------------------------------------|
| 45             |              | 144 6137    | PU tube                             |
| 46             |              | 143 4496    | O-ring                              |
| 47             |              | 143 6090    | Hose connector                      |
| 48             |              | 144 6131    | Hydraulic seal rings                |
| 49             |              | 144 6146    | Swivel                              |
| 50             |              | 144 6127    | Hydraulic hose                      |
| 51             |              | 144 6135    | Hose casing                         |
| 52             | <b>T5</b>    | 152 4522    | Hose connector cylinder             |
|                | <b>T6</b>    | 152 4523    | Hose connector cylinder             |
| 53             |              | 143 6103    | Spacer tube                         |
| 54             |              | 143 6092    | Cylinder adapter                    |
| 55             |              | 143 5486    | O-ring                              |
| 56             | <b>T5</b>    | 145 8013    | Air cylinder TAUREX 5               |
|                | <b>T6</b>    | 146 4043    | Air cylinder TAUREX 6               |
| 57             |              | 145 7956    | Silencer 3, complete                |
| 58             |              | 145 7750    | Pressure relief valve, complete     |
| 59             |              | 143 5484    | O-ring                              |
| 60             |              | 143 5667    | Connecting nipple                   |
| 61             |              | 144 6030    | Seal                                |
| 62             |              | 143 5648    | Spacer cage                         |
| 63             |              | 143 5647    | Rod seal                            |
| 64             |              | 143 5651    | Control piston                      |
| 65             |              | 143 5675    | Piston seal                         |
| 66             |              | 143 5652    | Piston housing                      |
| 67             |              | 143 5688    | O-ring                              |
| 68             |              | 144 6100    | Stopper 3                           |
| 69             |              | 144 5773    | Housing screw, short                |
| 70             |              | 143 5492    | Al nut                              |
| 71 •           | <b>T5</b>    | 143 6056    | Cylinder seal                       |
|                | <b>T6</b>    | 143 6007    | Piston seal                         |
| 72 •           | <b>T5</b>    | 143 6040    | Guide ring 5                        |
|                | <b>T6</b>    | 143 6006    | Guide ring 4                        |
| 73 •           | <b>T5</b>    | 143 6055    | Lip ring                            |
| 74             | <b>T5</b>    | 145 8015    | Air piston 5, complete              |
|                | <b>T6</b>    | 145 8024    | Air piston 6, complete              |
| 75 •           |              | 143 5937    | O-ring                              |
| 76             |              | 143 5635    | Rod seal                            |
| 77             |              | 144 6082    | V-profile ring                      |
| 78             |              | 143 5927    | O-ring                              |
| 79             | <b>T5</b>    | 145 8014    | Cylinder 5, complete                |
|                | <b>T6</b>    | 146 4044    | Cylinder 6, complete                |
| 80             |              | 143 6027    | Al bottom                           |
| 81             |              | 143 5900    | Rubber foot 3-4                     |
|                |              | 144 5294    | Hydraulic oil refill bottle, 100 ml |

