



## Operating Instructions for JSS-3/6/12 Jack Stands

### WARNING

- Never exceed rated capacity of the stand.
- Use stands only in pairs.
- Always make sure both stands are set at same height and holding dogs are fully engaged.
- Use stands only on hard and level surfaces.
- Always center load in saddles.
- Always use in locations specified by the vehicle manufacturer.
- Never crawl under a vehicle to place a stand.
- Always lower a vehicle slowly.
- Failure to heed all of the above warnings may cause serious injury and/or property damage.

### Specifications

Stock number	441003	441006	441012
Model number	JSS-3	JSS-6	JSS-12
Rated load capacity	6,000 lb (3T)	12,000 lb (6T)	24,000 lb (12T)
Minimum height	11-3/4"	15"	19"
Maximum height	17-1/4"	24-1/4"	30-3/8"
Saddle size	4-3/4" x 1-1/8"	4-7/8" x 1-1/8"	6-1/2" x 1-3/4"
Base size	7-5/8" x 8-5/8"	11-1/4" x 10"	12-3/8" x 14-1/4"
Weight (pair)	19 lb	34 lb	78 lb
Complies with ANSI/ASME PALD-4 standards			

Specifications were current at time of publication, but because of our policy of continuous improvement, Walter Meier (Manufacturing) Inc., reserves the right to change specifications at any time and without prior notice, without incurring obligations.




Fig. 1

### Prior to Operation

1. Check to make sure retaining tab on stand collar is bent in to keep rack bar from being pulled out. If tab is not bent in, bend using a punch and hammer. See Figure 1.
2. Check stand for bent, worn, loose or missing parts. Discard any stand that is damaged, badly worn, or operates abnormally.

### Operation

1. Raise vehicle to desired height. Vehicle must be stable with wheels blocked and parking brake set.
2. Extend both stands to same desired height. Confirm that holding dogs are fully seated in rack bars.
3. Place stands under support points specified by the vehicle manufacturer.
4. Carefully lower vehicle onto stands with support points centered in saddles. Make sure vehicle remains stable.

### Stand Removal

1. Confirm vehicle stability. Make sure wheels are blocked and the parking brake is set.
2. Carefully raise vehicle just enough to clear stands. Make sure vehicle remains stable.
3. Remove stands and carefully lower vehicle to the floor. Do not crawl under vehicle to remove stands.
4. Use release handle to lower stands to their lowest height.

### Lubrication

Lubricate release handle pivot points with motor oil.

### Repair

Replacement parts are not available for this stand. If repair is necessary, discard stand and replace.

### WALTER MEIER (Manufacturing) Inc.

427 New Sanford Road  
LaVergne, Tennessee 37086  
Ph.: 800-274-6848  
www.waltermeier.com

Part No. M-441003  
Revision G 01/2013

Copyright © 2013 Walter Meier (Manufacturing) Inc.

## Warranty and Service

Walter Meier (Manufacturing) Inc., warrants every product it sells. If one of our tools needs service or repair, one of our Authorized Service Centers located throughout the United States can give you quick service. In most cases, any of these Walter Meier Authorized Service Centers can authorize warranty repair, assist you in obtaining parts, or perform routine maintenance and major repair on your JET® tools. For the name of an Authorized Service Center in your area call 1-800-274-6848.

### MORE INFORMATION

Walter Meier is consistently adding new products to the line. For complete, up-to-date product information, check with your local Walter Meier distributor, or visit [jettools.com](http://jettools.com).

### WARRANTY

JET products carry a limited warranty which varies in duration based upon the product (MW = Metalworking, WW = Woodworking).

<b>90 DAY WARRANTY</b> Lathe Accessories Machine Accessories Mobile Bases Safety Equipment Specialty Items Vise Accessories	<b>1 YEAR WARRANTY</b> Air Tools-Contractor Air Tools-Industrial Air Tools-Light Industrial Lubrication	Body Repair Kits Bottle Jacks Cable Pullers Cold Saws Hoists-Air Hoists-Electric Metal forming Mill/Drills Milling Machines MW Bandsaws MW Drill Presses MW Finishing Equipment MW Lathes MW Precision Vises	<b>2 YEAR WARRANTY</b> Pallet Trucks Rigging Equip. Service Jacks Stackers Surface Grinders Tapping Trolleys-Air Trolleys-Electric Web Slings Winches-Electric	<b>3 YEAR WARRANTY</b> WW Benchtop Tools	Beam Clamps Chain Hoist-Manual Lever Hoists Pullers-JCH Models Scissor Lift Tables Screw Jacks Trolleys-Geared Trolleys-Plain Winches-Manual WW Air Filtration WW Bandsaws WW Buffers	<b>5 YEAR WARRANTY</b> WW Drill Presses WW Dust Collectors WW Dust Filters WW Dust Fittings WW Jointers WW Lathes WW Planers WW Sanders WW Shapers WW Tablesaws	<b>LIFE WARRANTY</b> Fastening Tools Mechanics Hand Tools Striking Tools Vises (no -precision) Clamps
Warranty reverts to 1 Year Warranty if woodworking (WW) products listed above are used for industrial or educational purposes.							

### WHAT IS COVERED?

This warranty covers any defects in workmanship or materials subject to the exceptions stated below. Cutting tools, abrasives and other consumables are excluded from warranty coverage.

### WHO IS COVERED?

This warranty covers only the initial purchaser of the product.

### WHAT IS THE PERIOD OF COVERAGE?

The general JET warranty lasts for the time period specified in the product literature of each product.

### WHAT IS NOT COVERED?

Five Year Warranties do not cover woodworking (WW) products used for commercial, industrial or educational purposes. Woodworking products with Five Year Warranties that are used for commercial, industrial or education purposes revert to a One Year Warranty. This warranty does not cover defects due directly or indirectly to misuse, abuse, negligence or accidents, normal wear-and-tear, improper repair or alterations, or lack of maintenance.

### HOW TO GET SERVICE

The product or part must be returned for examination, postage prepaid, to a location designated by us. For the name of the location nearest you, please call 1-800-274-6848.

You must provide proof of initial purchase date and an explanation of the complaint must accompany the merchandise. If our inspection discloses a defect, we will repair or replace the product, or refund the purchase price, at our option. We will return the repaired product or replacement at our expense unless it is determined by us that there is no defect, or that the defect resulted from causes not within the scope of our warranty in which case we will, at your direction, dispose of or return the product. In the event you choose to have the product returned, you will be responsible for the shipping and handling costs of the return.

### HOW STATE LAW APPLIES

This warranty gives you specific legal rights; you may also have other rights which vary from state to state.

### LIMITATIONS ON THIS WARRANTY

WALTER MEIER (MANUFACTURING) INC., LIMITS ALL IMPLIED WARRANTIES TO THE PERIOD OF THE LIMITED WARRANTY FOR EACH PRODUCT. EXCEPT AS STATED HEREIN, ANY IMPLIED WARRANTIES OR MERCHANTABILITY AND FITNESS ARE EXCLUDED. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG THE IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

WALTER MEIER SHALL IN NO EVENT BE LIABLE FOR DEATH, INJURIES TO PERSONS OR PROPERTY, OR FOR INCIDENTAL, CONTINGENT, SPECIAL, OR CONSEQUENTIAL DAMAGES ARISING FROM THE USE OF OUR PRODUCTS. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.

Walter Meier sells through distributors only. The specifications in Walter Meier catalogs are given as general information and are not binding. Members of Walter Meier reserve the right to effect at any time, without prior notice, those alterations to parts, fittings, and accessory equipment which they may deem necessary for any reason whatsoever. JET® branded products are not sold in Canada by Walter Meier.